# HANDLING

## INK CARTRIDGES

#### **STORAGE**

- Store in a 15 26 °C, dry and dark storage facility [no direct sunlight]
- · Remove ink cartridge from cartridge holder at the end of a working day or a break longer than 1 hour
- Seal ink cartridge by using AMACO cartridge cover KA2003 | Available upon request
- Store ink cartridge upside down on a flat surface in above mentioned conditions
- Avoid heat source exposure to expand life of ink cartridge [i.e. near window or sealing station]

#### **DURABILITY**

· Expiry approx. 1 year after date of delivery from AMACO when stored in above mentioned conditions

### **REACTIVATION | REUSE**

- Reactivate desiccated ink cartridge by pushing down ink pad several times. If there is still ink in the cartridge it
  will moisten the pad again
- Use AMACO cartridge tool | Available upon request
- Don't use sharp pointed device

#### **REFILL**

- Option only available for AMACO black ink catridge KA2003 110
- Refill black ink cartridge by using AMACO refill ink DF1210 & syringe with needle | Former available upon request
- Don't overfill ink cartridge | Final weight must not exceed 100 grams
- Use AMACO cartridge tool to moisten ink pad by pushing it down serveral times

#### **EXCHANGE**

- Switch off air supply by sliding of control box
- Move print head from basic position on cartridge to print position
- Remove ink cartridge from cartridge holder and insert new one

